

INTAKE AND OUTLET KEY:

Ⓟ PORT BALLAST INTAKE AND OUTLET


Ⓡ FRONT/CENTER BALLAST INTAKE AND OUTLET

Ⓢ STBD BALLAST INTAKE AND OUTLET

NOTE : BALLAST PUMPS ARE REVERSIBLE. INTAKE AND OUTLET ARE THE SAME.

Cobalt R4 SURF

TOP VIEW



BOTTOM VIEW

