


OUTLET KEY:

- ① PORT REAR OUTLET
- ② PORT MID OUTLET
- ③ BILGE OUTLET
- ④ STBD REAR OUTLET
- ⑤ STBD MID OUTLET
- ⑥ CENTER MID OUTLET
- ⑦ CENTER FORWARD OUTLET

NOTE : BALLAST PUMPS ARE REVERSIBLE. INTAKE AND OUTLET ARE THE SAME ON HULL BOTTOM.  
THROUGH HULL FITTINGS ON HULL SIDE ARE BALLAST TANK VENT LOCATIONS.

Cobalt R6 SURF  
R8 SURF

PORT VIEW



STBD VIEW

